

Oracle Fountains™

By Ecosphere Associates, Inc.

4421 N. ROMERO ROAD (520) 888-0084

TUCSON, AZ 85705 FAX (520) 888-3380

e-mail : service@oraclefountains.com

Assembly and Instructions

Congratulations on the purchase of your new **Alto** Fountain.

Check for any damage that may have occurred during shipping. If any damage to the fountain is noticed during unpacking, keep the packing and notify the carrier immediately for an Inspection.

WARNING: As with any fountain there is a risk of water damage due to splashing or leakage. Do not place fountain where it could cause damage to fine furniture or other items. Do not overfill base. Splashing can occur on start up.

Alto Assembly:

- Make sure pump is connected to the valve and the valve is connected to the sphere.
- Fill basin with water and plug in pump.
- Pump can be adjusted with knob adjustment on valve.

Maintenance:

- Add water as necessary.
- To keep fountain clean of algae and bacteria add 1 teaspoon of bleach every 4 to 5 days. To avoid damage to pump and components do not add more bleach than is recommended.
- If you notice air bubbles coming from the pump you probably need to add more water.

Warranty is limited to repair or replacement of product, at Ecosphere's option. Ecosphere reserves the right to repair any part prior to complete replacement. Ecosphere is not liable for any consequential damages. Warranty period is six months on pumps, and one year on all other parts. No warranty on breakage. Warranty void if pump is run dry or cracked due to freezing. Defective pumps in warranty must be returned to Ecosphere by US mail and if found defective will be replaced free of charge. **All fountain returns require a RA # and must be shipped prepaid.** Any product returned without an RA # will not be accepted. Any questions can be directed to our customer service department at 1-800-729-9870.

041603

ALTO T ASSEMBLY

